# **Technical Support**

Should you have any questions regarding your M23 microphone please contact us:

e-mail: Support@EarthworksAudio.com phone: 1-603-654-6427 (9a.m. – 5p.m. ET)

For warranty and product return/exchange information please refer to the back of the enclosed Calibration Chart.



Earthworks, Inc. 37 Wilton Rd. Milford, NH 03055 USA Phone: 1-603-654-6427 Fax: 1-603-654-6107 www.EarthworksAudio.com



M23 Measurement Microphone Owner's Manual





Made in U.S.A.

### Description

Earthworks M23 is an omnidirectional (pressure) microphone designed and calibrated for measurement purposes. It is a prepolarized condenser microphone directly coupled to a wideband, low output impedance preamplifier. The M23 requires a standard 48V phantom power supply. It features a linear free-field frequency response from 9Hz to 23kHz (please see the enclosed individual calibration chart), very low handling noise, uniform polar pattern, and very high SPL handling capabilities. Its unique circuitry excludes the transconductance of the input FET from the overall gain structure. This means the sensitivity remains very stable when the microphone is subjected to variations in ambient temperature. The M23 meets or exceeds ANSI Type 1 requirements.

Each microphone is delivered with its own calibration chart providing its individually measured open-circuit sensitivity and the frequency response curve. A computer file containing the frequency response data for importing directly into measurement software is available from Earthworks, Inc. upon request at an extra cost. A mounting clip and a calibrator adapter are included with the microphone.

## Applications

Earthworks M23 is ideally suited for acoustical measurements sound system setup and troubleshooting, room acoustics, or any application where an accurate free-field measurement microphone is required. The wide linear minimum-phase response and fast welldamped impulse response (Fig. 2) make the M23 an excellent microphone for room acoustics measurements, especially for time domain measurements. The M23 is simple to operate. Connect the microphone to a microphone preamplifier supplying 48V phantom power using a standard XLR microphone cable. *Please allow up to one minute for the microphone to settle.* Plugging in the microphone "hot" (phantom power already present at the input) will not damage the microphone, and is actually preferred for faster settling. For optimum results we recommend pointing the M23 toward the sound source.

This microphone has no removable parts.

## Calibration

The microphone is calibrated at the factory at 1 kHz (therefore independent of any frequency weighting). The sensitivity in mV/Pa is provided on the calibration chart. If on-site calibration is required, use the enclosed  $V_2$ " adapter.

## **Specifications**

Frequency response: Polar Pattern: Sensitivity: Power Requirements: Peak Acoustic Input: Output: Output Impedance: Minimum Load: Noise:

Dimensions L x D

Weight:

**CE** Compliant

Specifications are subject to change without notice.

9Hz to 23kHz +1/-3dB Omnidirectional 30mV/Pa (Typical) 48V Phantom, 10mA 142dB SPL XLR (Fig. 1) 100 $\Omega$ , balanced (50 $\Omega$  ea. pin 2 & 3) 600 $\Omega$  btw. pins 2 & 3 22dB, A equivalent 229 x 22 mm (9 x .860 in.) 160q (.3lb)




Fig. 1. XLR Output Connector Assignment of M23



Fig. 2. Impulse Response (Typical) of M23




Fig. 3. Polar Response (Typical) of M23, 1dB/div.